

1967 to 72 GM & GMC Truck AC Delete Cover

How to install the firewall extension to the AC Delete Cover



You will need a 5/32" drill bit, standard drill, either a 3M black silicon, or windshield ribbon (as pictured below).



Start by drilling the marked indentations into the smaller extension, then align the extension to the AC Delete cover, and drill the remaining holes. (as shown above)



Next, use either the 3M silicon, or the windshield ribbon to provide a good seal from the extension to the AC Delete cover.



Using the hardware provided (#6 machine screws and nuts) insert the screws making sure not to brake the bead of silicon or ribbon.



Attach the extension to the new AC Delete cover using the nuts provided. To keep the nuts from coming loose use a small amount of silicon on the end of the screw.



When installing the complete cover make sure to use a generous amount of silicon to seal the extension to the firewall.